

mm PT420

Description

- Absolute Linear Position
- Classic Stringpot Design
- Stroke Range Options: 0-2 to 0-100 inches
- Powder Painted & Anodized Aluminum Enclosure
- Industrial Automation & Testing Applications

The PT420 is available with full-scale measurement ranges from 2 to 100 inches, providing a 0/4-20 mA feedback signal that is linearly proportional to the position of a traveling stainless-steel extension cable. Use the PT420 to provide position feedback on hydraulic cylinders in factories and utilities, gate position in fresh or wastewater distribution systems, or valve opening in process-related applications.

The PT420 installs in minutes by mounting its base to a fixed surface and attaching its cable to the movable object. The PT420 works without perfect parallel alignment, and when its stainless steel cable is retracted, its height is less than 5".

GENERAL

Full Stroke Range Options	0-2 to 0-100 inches
Output Signal Options	420 mA (2-wire) and 020 mA (3-wire)
Accuracy	see ordering information
Repeatability	± 0.05% full stroke
Resolution	essentially infinite
Enclosure Material	powder-painted and anodized aluminuml
Sensor	plastic-hybrid precision potentiometer
Weight	2 lbs. max.

4.6° [117 mm]* ↓ 2.6″ [66 mm]* ↓

*50-inch range model, dimensions may differ for other ranges

ELECTRICAL Input Voltage see ordering information Input Current 20 mA max. (loop supply voltage - 8)/0.020 Maximum Loop Resitance (Load) **Circuit Protection** 38 mA max. Impedence 100M ohms@100 VDC, min. Signal Adjustment, Zero from factory set zero to 50% of full stroke range Signal Adjustment, Span to 50% of factory set span Thermal Effects, Zero 0.01% f.s./°F, max. Thermal Effects, Span 0.01% f.s./°F, max.

ENVIRONMENTAL

Enclosure	IP50, NEMA 1
Operating Temperature	-40° to 200°F (-40° to 90°C)
Vibration	up to 10 g to 2000 Hz maximum

Electrical Output Signal



*Optional 3-wire, 0...20mA output signal available.





Fig. 1, Top Exit:



ALL DIMENSIONS ARE IN INCHES [MM] · tolerances are ± 0.02 in. [± 0,5mm]

Range	A	В		D	E	F	G	Н	
2", 10", 20"	1.34 [34,0] 4	+.00 [101,6] 7.	00 [177,8]	2.00 [50,8]	2.63 [66,8]	7.50 [190,5]	2.10 [53,3]	.16 [4,1]	1.37 [34,8]
5", 25", 50"	1.83 [46,5] 4	+.00 [101,6] 7.	00 [177,8]	2.00 [50,8]	2.63 [66,8]	7.50 [190,5]	2.10 [53,3]	.16 [4,1]	1.37 [34,8]
15", 30"	1.56 [39,6] 4	+.00 [101,6] 7.	00 [177,8]	2.00 [50,8]	2.63 [66,8]	7.50 [190,5]	2.10 [53,3]	.16 [4,1]	1.37 [34,8]
40″	1.64 [41,6] 4	+.00 [101,6] 7.	00 [177,8]	2.00 [50,8]	2.63 [66,8]	7.50 [190,5]	2.10 [53,3]	.16 [4,1]	1.37 [34,8]
60"	2.16 [54,9] 4	.19 [106,4] 7.	00 [177,8]	2.37 [60,2]	3.25 [82,5]	7.50 [190,5]	2.60 [66,0]	.19 [4,8]	1.37 [34,8]
75", 80"	2.45 [62,2]	4.38 [111,3] 6	.75 [171,4]	2.50 [63,5]	3.63 [92,2]	7.50 [190,5]	2.86 [72,6]	.19 [4,8]	1.37 [34,8]
100"	3.10 [78,7] 4	+.19 [106,4] 7.3	38 [187,5]	3.00 [76,2] 4	+.25 [108,0] 8	8.00 [203,2]	3.79 [96,3]	.19 [4,8]	3.69 [93,7]

Ordering Information



 \star -1 cycle is defined as the travel of the measuring cable from full retraction to full extension and back to full retraction



Ordering information (cont.)

Measuring Cable Tension:

Α	order code:				Н			2*		3*		
		standard tension			high tension			<pre>{*note - outline dimensions for these options } are not controlled on this datasheet!</pre>				
2 10 2	0 inch canao:	12 07		11 0	65.07		52 0		72 07		1// 07	,
2, 10, 2		īz υz.	•	11 y	05 02.	•	JJ y		72 02.		144 UZ.	
5, 25, 5	ou inch range:	5 OZ.	•	z g	26 OZ.	•	II g		30 0Z. 00		60 000	
15, 30 i	nch range: 40	8 oz.	•	3 g	43 oz.	•	23 g		4808	-5	Pa oz.	
	inch range:	6 oz.	•	4 g	33 oz.	•	16 g	-0	R OZ.	COR!	72 oz.	
6	0 inch range:	13 oz.	•	4 g	22 oz.	•	8 g	REU	26 oz.	RES	52 oz.	
75, 8	0 inch range:	10 oz.	•	3 g	31 oz.	•	12 g	·	20 oz.		40 oz.	
10	0 inch range:	13 oz.	•	5 g	52 oz.	•	20 g		26 oz.		52 oz.	
me	asuring cable:	019-in dia nylon-coated stainless steel							024	-in dia stainl	ess steel	

Measuring Cable Exit:



*-note: dimensions for optional cable exits not controlled on this datasheet, please contact factory

Sensing Circuit:







The output signal direction can be reversed at any time by simply changing the dip-switch settings found on the internal signal board. After the settings have been changed, adjust- ment of the Zero and Span trimpots will be required to precisely match signal values to the beginning and end points of the stroke.





dip-switch location



internal dip switches & signal board

To gain access to the signal board, remove the two 4-40 screws on top and lift up cover.

The information provided herein is to the best of our knowledge true and accurate, it is provided for guidance only. All specifications are subject to change without prior notification. Althen - Your expert partner in Sensors & Controls | althensensors.com

Althen stands for pioneering measurement and custom sensor solutions. In addition we offer services such as calibration, design & engineering, training and renting of measurement equipment.

Germany/Austria/Switzerland info@althen.de

Benelux sales@althen.nl

France info@althensensors.fr Sweden info@althensensors.se USA/Canada info@althensensors.com Other countries info@althensensors.com

Page 4/4