

AUTHORIZED DISTRIBUTOR

175-inch model shown



SR1A is a rugged, low-cost, high performance string pot built for wet environments and outdoor applications. Originally designed for off-road construction equipment, the SR1A is the perfect low-cost solution for OEM and stocking distributors.

Available in 62-inch, 125-inch and 175-inch stroke ranges, the SR1A is constructed of a rugged polycarbonate enclosure designed to withstand impact from harsh environments and rugged conditions. Each sensor ships with a handy mounting bracket to make just about any installation very simple. Every SR1A ships with a field installable mating connector and optional cordsets are available.

SR1A **Cable Actuated Sensor** Industrial • Voltage Divider Output

Precision Potentiometric (Voltage Divider) Output 0-62, 0-125 and 0-175 inch Range Options **Designed for Outdoor & IP67 environments** In Stock for Quick Delivery!

Specifications

Measurement Range, SR1A-62	0–62 in. (0–1575 mm)
Measurement Range, SR1A-125	0–125 in. (0–3175 mm)
Measurement Range, SR1A-175	0–175 in. (0–4445 mm)
Accuracy	± 0.5% FS.
Sensor	plastic-hybrid precision potentiometer
Input Resistance	10K ohms
Maximum Input Voltage	30 volts AC/DC
Resolution	essentially infinite
Repeatability	± 0.1% FS.
Measuring Cable	.034-inch dia. nylon-coated stainless
Maximum Velocity	80 inches (2 meters) per second
Maximum Acceleration	10 g (retraction)
Measuring Cable Tension	23 oz. (6,4 N) ±30%
Cycle Life	250,000 (potentiometer)
Enclosure	Polycarbonate
Electrical Connection	M12 Connector (mating plug included)
Environmental Suitability	NEMA 6, IP67
Operating Temperature	-40° to 185° F (-40° to 85° C)
Weight	2.5 lbs. (1.3 Kg)

Output Signal



SENSOR SOLUTIONS /// SR1A

ALTHEN **SENSORS & CONTROLS** Germany/Austria/Switzerland info@althen.de

Benelux sales@althen.nl

12//2015

France

Sweden info@althensensors.fr info@althensensors.se

USA/Canada

Other countries info@althensensors.com info@althensensors.com

Electrical Connection



Changing the Cable Exit

Changing Measuring Cable Exit

To change the direction of the measuring cable, remove the 4 mounting bracket screws and rotate bracket to one of four available positions. See figures 1 - 4 on the following pages for mounting dimensions.

Changing Electrical Connector Direction

To change the position of the electrical connector, remove the 4 rear cover screws and carefully separate rear cover from the sensor body.

Rotate the rear cover to desired position being careful to not tangle the wiring harness that runs to the connector.



SENSOR SOLUTIONS /// SR1A

ALTHEN **SENSORS & CONTROLS** Germany/Austria/Switzerland Benelux info@althen.de

sales@althen.nl

12//2015

France info@althensensors.fr info@althensensors.se

Sweden

USA/Canada Other countries info@althensensors.com info@althensensors.com

Fig. 1 - Outline Drawing (as shipped)



Fig. 2 - "Up" Cable Exit Direction



SENSOR SOLUTIONS /// SR1A 12//2015

ALTHEN SENSORS & CONTROLS Germany/Austria/Switzerland Benelux info@althen.de

France

Sweden

USA/Canada

Other countries $sales (\texttt{Palthen.nl} info (\texttt{Palthensensors.fr} info (\texttt{Palthensensors.se} info (\texttt{Palthensensors.com} info (\texttt{P$

Fig. 3 - "Down" Cable Exit Direction



Fig. 4 - "Rear" Cable Exit Direction



units are in inches [mm] tolerances are \pm .04 [1,0] unless otherwise noted

SENSOR SOLUTIONS /// SR1A 12//2015

ALTHEN SENSORS & CONTROLS Germany/Austria/Switzerland Benelux info@althen.de

France

Sweden

USA/Canada

Ordering Information



The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

SR1A 12/01/2015

SENSOR SOLUTIONS /// SR1A 12//2015



France info@althensensors.fr

Sweden