



# PT9232

## Description

- Linear Position/Velocity to 550 inches (1400 cm)
- Aluminum or Stainless Steel Enclosure Options
- VLS Option To Prevent Free-Release Damage
- IP68 NEMA 6 Protection




The PT9232 delivers position feedback via RS232 serial communication to your data acquisition or controller system. The PT9232 sends a raw 16-bit count from 0000H to FFFFH. Additionally this device can be set to continuously send data or send data only when polled.

As the internal position sensing element is a precision potentiometer, this transducer maintains current accurate position even during power loss and does not need to be reset to a "home" position.


#### **GENERAL**

Full Stroke Ranges		0-75 to 0-550 inches
Electrical Interface		RS232
Format		HEX
Accuracy		± 0.10% full stroke
Repeatability		± 0.02% full stroke
Resolution		± 0.003% full stroke
Measuring Cable	sta	inless steel or thermoplastic
Enclosure Material	powder-painted alun	ninum or 303 stainless steel
Sensor	plastic-hyb	rid precision potentiometer
Potentiometer Cycle Life	2	≥ 250,000 cycles
Maximum Retraction Ac	celeration	see ordering information
Maximum Velocity		see ordering information
Weight, Aluminum (Stair	nless Steel) Enclosure	8 lbs. (16 lbs.), max.
ELECTRICAL		
Input Voltage		922 VDC
Input Current		40 mA
Baud Rate		9600 (selectable to 38.4K)
Update Rate		32 msec
511111501111511511		
ENVIRONMENTAL		

Enclosure	NEMA 4/4X/6, IP 67/68
Operating Temperature	-40° to 200°F (-40° to 90°C)
Vibration	up to 10 g to 2000 Hz maximum



## Output signal



#### I/O Format



#### Data Format



# 6 byte Hex string:

 STX
 CMD
 B<sub>0</sub>
 B<sub>1</sub>
 B<sub>2</sub>
 ETX

 STX = 0x02
 CMD = Command Code\*
 B<sub>0</sub> - B<sub>2</sub> = Data Field\*
 ETX = 0x03

Data Frame

\* -see below

Important! All communications to/from the transducer are in HEX!

User Commands:

## **User Command**

### Sensor Response

Description	<cmd></cmd>	<b<sub>0&gt;</b<sub>	<b<sub>1&gt;</b<sub>	<b<sub>2&gt;</b<sub>	<cmd></cmd>	<b<sub>0&gt;</b<sub>	<b<sub>1&gt;</b<sub>	<b<sub>2&gt;</b<sub>
Get sen sor Info	0x05	0x00	0x00	0x00	0x05	version <sup>(4)</sup>	date <sup>(5)</sup>	date <sup>(5)</sup>
Get Serial Number	0x15	0x00	0x00	0x00	0x15	se	rial number	<sub>r</sub> (3)
Start Continuous Data	0x25	0x00	0x00	0x00	0x25	0x00	0x00	0x00
Stop Continuous Data	0x35	0x00	0x00	0x00	0x35	0x00	0x00	0x00
Get Position Data	0x45	0x00	0x00	0x00	0x45	CMC <sup>(1)</sup>	$CMC^{(1)}$	status <sup>(2)</sup>

(1)CMC - Current Measurement Count (Position)

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable.

The CMC is a 16-bit value that occupies the first two bytes ( $B_0$  and  $B_1$ ) of the data field.  $B_0$  is the MSB (most significant byte) and  $B_1$  is the LSB (least significant byte).

The CMC starts at 0000H with the measuring cable fully retracted and continues upward to the end of the stroke range stopping at FFFFH. This holds true for all ranges.

(2)Status

The status byte is used as a flag to indicate the validity of the position signal that the internal electronics receives from the potentiometer.

Flags are as follows:

0x00 = GREEN, 0x55 = YELLOW, 0xAA = RED

A "green" flag shows everything OK. A "yellow" or "red" flag indicates that the sensor has either been extended beyond its range or that there is a problem with the potentiometer.

(3)Serial Number

Each sensor has it's own unique serial number. This information can be retrieved by sending the sensor the "Get Serial Number" command.

The serial number is a 3 byte value from which ranges from 0 to 9999999 (decimal).

<sup>(4)</sup>Version

This is a single byte value (0-255 decimal) which indicates the currently installed firmware version of the sensor.

## <sup>(5)</sup>Date

This is a 2 byte value showing the date of currently installed firmware. This value ranges from 01011 - 12319 (decimal). Format is MMDDY. While the month and day are expressed as two digit numbers the year is expressed in a single digit only.

Example: 08054 = August 5, 2004

#### **Baud Rate**


The baud rate can be set using switches 7 & 8 on the 8-pole DIP switch found on the rs232 controller board located inside the transducer.

DIP-7	DIP-8	baud rate
0	0	9600
1	0	19200
0	1	38400
1	1	9600




### RS232 Controller Board and DIP Switch Location

#### baud rate switches



Caution! Do Not Remove Spring-Side End Cover removing spring-side end cover could cause spring to become unseated and permanently damaged.





internal dip switches & controller board

to gain access to the controller board, remov four Allen-Head Screws and remove end cover bracket.




Fig. 1 – Outline Drawing (18 oz. cable tension only)






DIMENSIONS ARE IN INCHES [MM] tolerances are 0.03 IN. [0.5 MM] unless otherwise noted.



	A DIME	ENSION	(INCHES	5)
		MEASU	RINGCAE	BLE
RANGE	Ø.031 iı	n. Ø.034 in.	Ø.047 in.	Ø.062 in.
75	n/a	0.22	0.29	0.37
100	n/a	0.29	0.39	0.49
150	n/a	0.44	0.59	0.73
200	n/a	0.58	0.79	0.98
250	n/a	0.73	0.98	1.22
300	n/a	0.88	1.18	1.47
350	n/a	1.02	1.38	1.71
400	n/a	1.17	1.57	1.96
450	n/a	1.31	1.77	n/a
500	n/a	1.46	1.97	n/a
550	1.61	1.61	n/a	n/a



- \* tolerance = +.005 -.001 [+.13 -.03] \*\* tolerance = +.005 -.005 [+.13 -.13]

## Ordering Information

## Model Number



#### Sample Model Number:

PT9232 - 200 - AL - N34 - 26 - FR - M6

- R range:
- anige.

  enclosure
  enclosure
  measuring cable:
  measuring cable tension:
  cable exit:
  connection:
  - front (horizontal) electrical 6-pin plastic connector

# Full Stroke Range

R order code:	75	100	150	200	250	300	350	400	450*	500*	550*
full stroke range, min:	75 in.	100 in.	150 in.	200 in.	250 in.	300 in.	350 in.	400 in.	450 in.	500 in.	550 in.

\* - 36 oz. cable tension strongly recommended

200 inches

aluminum

18 oz.

.034 nylon-coated stainless



## Ordering Information (cont.)

# **Enclosure Material**

A order code:	AL	SS
	powder-painted aluminum	303 stainless


# Measuring Cable

B order code:	N34	S47	S31	V62
cable construction:	Ø.034-inch nylon-coated stainless steel rope	Ø.047-inch bare stainless steel rope	Ø.031-inch bare stainless steel rope	Ø.058-inch PVC jacketed vectra fiber rope
available ranges:	all ranges	all ranges up to 500 inches	550 inch range only	all ranges up to 400 inches
general use:	indoor	outdoor, debris, high temperature	outdoor, debris, high temperature	high voltage or magnetic field

# Measuring Cable Tension

🕻 order code:	26	52
tension (30%):	18 oz.	36 oz.
enclosure material:	aluminum stainless steel	aluminum stainless steel
max. acceleration:	1 G .33 G	5 G 2 G
max. velocity:	60 inches/sec 20 inches/sec	200 inches/sec 80 inches/sec
	standard housing see fig 1.	dual-spring housing see fig 2.


# Cable Exit



# **Electrical Connection**



6-pin plastic connector with mating plug IP 67, NEMA 6, NEMA 4X (stainless enclosure only)




.30 — .39 in. [8 — 10 mm] cable dia. 16 AWG max conductor size connector: MS3102E-14S-6P mating plug: MS3106E-14S-6S



pin	signal
Α	922 VDC
В	common
C	_
D	Transmitted Data
E	Received Data
F	common


25-ft. instrumentation cable 24 AWG, shielded IP 67, NEMA 6




color code	signal
Red	922 VDC
Black	common
White	_
Green	Transmitted Data
Blue	Received Data
Brown	common



Fig. 2 – Outline Drawing (36 oz. cable tension only)






DIMENSIONS ARE IN INCHES [MM] tolerances are 0.03 IN. [0.5 MM] unless otherwise noted.

## mounting hole detail eyelet detail Ø.191 [4,19]\* 0.64 [16,3] Ø.375 [9,52]\*\* .165 [4,19]\*\* 0.27 [6.9]

	A DIME	NSION (	INCHES	)
		MEASU	RINGCAB	LE
RANGE	Ø.031 in	. Ø.034 in.	Ø.047 in.	Ø.062 in.
75	n/a	0.22	0.29	0.37
100	n/a	0.29	0.39	0.49
150	n/a	0.44	0.59	0.73
200	n/a	0.58	0.79	0.98
250	n/a	0.73	0.98	1.22
300	n/a	0.88	1.18	1.47
350	n/a	1.02	1.38	1.71
400	n/a	1.17	1.57	1.96
450	n/a	1.31	1.77	n/a
500	n/a	1.46	1.97	n/a
550	1.61	1.61	n/a	n/a



- \* tolerance = +.005 -.001 [+.13 -.03] \*\* tolerance = +.005 -.005 [+.13 -.13]

## VLS Option - Free Release Protection

The patented Velocity Limiting System (VLS) is an option for PT9000 Series cable extension transducers that limits cable retraction to a safe 40 to 55 inches per second for the single spring option and 40 to 80 inches per second for the higher tension dual spring option.

The VLS option prevents the measuring cable from ever reaching a damaging velocity during an accidental free release. This option is ideal for mobile applications that require frequent cable disconnection and reconnection. It prevents ex- pensive unscheduled downtime due to accidental cable mishandling or attachment failure. How To Configure Model Number for VLS Option:



creating VLS model number (example)...

- 1. select PT9232 model
- 2. remove "PT" from the model number
- 3. add "VLS"
- 4. completed model number!

PT9232-0100-111-1110

**№** 9232-0100-111-1110

VLS + 9232-0100-111-1110

VLS9232-0100-111-1110

Page 5/5

The information provided herein is to the best of our knowledge true and accurate, it is provided for quidance only. All specifications are subject to change without prior notification.